



82mm TB Information

Please note that you must adapt this TB via STAR once installed. Your idle must also be raised by 60 RPM. Failure to do so may cause a CEL for Idle Control.

During installation you must swap some pins on the male end of the cable that plugs into the throttle body. The pins are clearly marked on the end of the connector

Swap Pin 1 with Pin 4

Swap Pin 5 with Pin 6

To install the Y-Pipe, please follow these instructions:

1. Take out the plastic ring



2. Remove the rubber O ring attached. You will not use the plastic part



3. Flip the rubber O ring and put that on the TB.



Y-Pipe should fit snug at that point. The clips no longer work in this configuration work, the airbox should hold it in place